

To ensure proper installation of SpotOn printable PVC film, please follow the recommendations listed.

## INSTALLATION INSTRUCTIONS

### RECOMMENDATIONS FOR INSTALLATION

1. Use care when transporting the graphic and removing the release liner. The graphic should not be bent or distorted because the film will not flatten after being creased.
2. SpotOn will adhere to most smooth surfaces such as glass, aluminum, stainless steel, plastics, and laminated surfaces. SpotOn can be used on painted drywall as well, but care must be used during removal to prevent wall damage.  
**Please Note:** The clear version of SpotOn should not be used on any surface where moisture may be present. Moisture may become trapped behind the film due to its dot patterned adhesive and may cause a cloudy appearance.
3. The surface where the graphic is to be applied must be clean and free of dust and dirt particles. These types of inclusions may cause small air pockets in the image.
4. Prior to application, clean the surface with a soap and water mixture. Use a window squeegee to remove any excess water and wipe the edges dry with a lint-free cloth. Window cleaners or other chemical products are not recommended as they can leave streaks or residue on the surface.
5. A low tack tape, such as painter's tape, can be used to position the graphic in the correct location and straight on the surface. Put a small piece of tape on the surface to help line up the top and side edges of the graphic.
6. Do not completely remove the release liner before starting the application process. Pull it back a few inches on the edge of the graphic and fold the release liner to create a hinge.
7. Position the graphic's exposed adhesive in the location that was marked beforehand with the tape. With a felt pad, apply the edge of the graphic to the surface. Work toward the opposite edge of the graphic, slowly pulling the release liner to gradually expose the adhesive and working from top to bottom as the graphic is installed.
8. When installing the graphic, carefully work out any air bubbles with a felt pad. The graphic can be pulled back and re-installed, if needed. It can also be re-positioned during installation.

#### IMPORTANT NOTE:

Please refer to the SpotOn TDS and for more information. The technical information, recommendations and other statements contained in this document are based upon testing and experience Drytac believes to be reliable, but the accuracy and or completeness is not guaranteed. Drytac recommends a small test be performed to determine suitability beforehand. This document does not constitute a warranty of any kind.

**For more information, please contact your local Drytac office.**

© 2018 Drytac Corporation. E&OE.  
All other trademarks are the property of their respective owners.



[www.digitalcolorink.com](http://www.digitalcolorink.com)  
877-616-8600  
Baltimore, MD | Charlotte, NC

# DRYTAC<sup>®</sup>

## ADHESIVE SCIENCE

#### Europe

Filwood Road,  
Fishponds,  
Bristol, BS16 3RY,  
United Kingdom  
[bristol@drytac.com](mailto:bristol@drytac.com)  
Tel: +44 (0) 117 958 6500

#### Canada

105 Nuggett Court,  
Brampton,  
Ontario, L6T 5A9,  
Canada  
[toronto@drytac.com](mailto:toronto@drytac.com)  
Tel: +1 800.353.2883

#### USA

5601 Eastport Boulevard,  
Richmond,  
Virginia, 23231,  
USA  
[customerservice@drytac.com](mailto:customerservice@drytac.com)  
Tel: +1 800.280.6013